









E.X.PZ.KZ-S
E.A.PZ.KZ-S













Xesar & AirKey



Montageanleitung | Assembly manual | Montagehandleiding
Instructions de montage | Istruzioni di montaggio | Montážní návody
Montážne návody | Instrukcje montażu | Installationsanvisningar






1




IP65 ✓




max. 0,5 Nm




2




1



2







3





IP65




3




4



60°



2




~5x



2




5




1


40°



2




max. ~ 60°




EVVA



CLICK




6




1

AirKey



Xesar





2





CHECK



7





1



1

AirKey


Xesar





8



max. 4 Nm






9



10



CHECK



1

AirKey

Xesar



NEW



11

AirKey



<https://airkey.evva.com>

Xesar



CE



www.evva.com

EVVA Sicherheitstechnologie GmbH | Wienerbergstraße 59-65 | A-1120 Wien

L:AN.MNTE.KZ:5:SN | 20R1