










E.X.PZ.HZ-S
E.A.PZ.HZ-S











Xesar & AirKey




Montageanleitung | Assembly manual | Montagehandleiding
Instructions de montage | Istruzioni di montaggio | Montážní návody
Montážne návody | Instrukcje montażu | Installationsanvisningar








1




max. 0,5 Nm







4




1




60°




2




~5x



5



2



1


40°




EVVA

3

max. ~ 60°






6



1

AirKey



Xesar




CHECK



7




1



2

AirKey

Xesar





1

8






max. 4 Nm



9



CHECK



1

AirKey

Xesar





10

AirKey



<https://airkey.evva.com>

Xesar



CE



www.evva.com

EVVA Sicherheitstechnologie GmbH | Wienerbergstraße 59–65 | A-1120 Wien

WTD.MTA.E.HZ-SV4.LN.SN